

DISPENSER KIT MANUAL

TO INSTALL

Drill suitable holes in the wall, using 10mm masonry drill bit. Mount dispenser using bolts and plugs provided.

TO REFILL

Follow instructions to refill (see diagram below)

REMOVE END CAPS AND PLASTIC SEALS FROM BOTH END OF NEW CARTRIDGE BEFORE USE !



10. CRANK HANDLE UNTIL HAND CLEANER DISCHARGES FROM OUTLET LOCATED ON BASE